



Smarter. Greener. Together.

## Industrial Automation Headquarters

**Delta Electronics, Inc.**  
Taoyuan Technology Center  
No.18, Xinglong Rd., Taoyuan District,  
Taoyuan City 33068, Taiwan  
TEL: 886-3-362-6301 / FAX: 886-3-371-6301

## Asia

**Delta Electronics (Shanghai) Co., Ltd.**  
No.182 Minyu Rd., Pudong Shanghai, P.R.C.  
Post code : 201209  
TEL: 86-21-6872-3988 / FAX: 86-21-6872-3996  
Customer Service: 400-820-9595

**Delta Electronics (Japan), Inc.**  
Tokyo Office  
Industrial Automation Sales Department  
2-1-14 Shibadaimon, Minato-ku  
Tokyo, Japan 105-0012  
TEL: 81-3-5733-1155 / FAX: 81-3-5733-1255

**Delta Electronics (Korea), Inc.**  
Seoul Office  
1511, 219, Gasan Digital 1-Ro., Geumcheon-gu,  
Seoul, 08501 South Korea  
TEL: 82-2-515-5305 / FAX: 82-2-515-5302

**Delta Energy Systems (Singapore) Pte Ltd.**  
4 Kaki Bukit Avenue 1, #05-04, Singapore 417939  
TEL: 65-6747-5155 / FAX: 65-6744-9228

**Delta Electronics (India) Pvt. Ltd.**  
Plot No.43, Sector 35, HSIIDC Gurgaon,  
PIN 122001, Haryana, India  
TEL: 91-124-4874900 / FAX : 91-124-4874945

**Delta Electronics (Thailand) PCL.**  
909 Soi 9, Moo 4, Bangpoo Industrial Estate (E.P.Z),  
Pattana 1 Rd., T.Phraksa, A.Muang,  
Samutprakarn 10280, Thailand  
TEL: 66-2709-2800 / FAX : 662-709-2827

**Delta Energy Systems (Australia) Pty Ltd.**  
Unit 20-21/45 Normanby Rd., Notting Hill Vic 3168, Australia  
TEL: 61-3-9543-3720

## Americas

**Delta Electronics (Americas) Ltd.**  
Raleigh Office  
P.O. Box 12173, 5101 Davis Drive,  
Research Triangle Park, NC 27709, U.S.A.  
TEL: 1-919-767-3813 / FAX: 1-919-767-3969

**Delta Greentech (Brasil) S/A**  
São Paulo Office  
Rua Itapeva, 26 – 3º Andar - Bela Vista  
CEP: 01332-000 – São Paulo – SP - Brasil  
TEL: 55-11-3530-8642 / 55-11-3530-8640

**Delta Electronics International Mexico S.A. de C.V.**  
Mexico Office  
Vía Dr. Gustavo Baz No. 2160, Colonia La Loma,  
54060 Tlalnepantla Estado de Mexico  
TEL: 52-55-2628-3015 #3050/3052

## EMEA

**Delta Electronics (Netherlands) BV**  
Eindhoven Office  
De Witbogt 20, 5652 AG Eindhoven, The Netherlands  
MAIL: Sales.IA.EMEA@deltaww.com  
MAIL: Sales.IA.Benelux@deltaww.com

**Delta Electronics (France) S.A.**  
ZI du bois Chaland 2 15 rue des Pyrénées,  
Lisses 91056 Evry Cedex, France  
MAIL: Sales.IA.FR@deltaww.com

**Delta Electronics Solutions (Spain) S.L.U**  
Ctra. De Villaverde a Vallecas, 265 1ª Dcha Ed.  
Hormigueras – P.I. de Vallecas 28031 Madrid  
C/Llull, 321-329 (Edificio CINC) | 22@Barcelona, 08019 Barcelona  
MAIL: Sales.IA.Iberia@deltaww.com

**Delta Electronics (Italy) Srl**  
Ufficio di Milano Via Senigallia 18/2 20161 Milano (MI)  
Piazza Grazioli 18 00186 Roma, Italy  
MAIL: Sales.IA.Italy@deltaww.com

**Delta Electronics (Germany) GmbH**  
Coesterweg 45, D-59494 Soest, Germany  
MAIL: Sales.IA.DACH@deltaww.com

**Delta Energy Systems LLC (CIS)**  
Vereyskaya Plaza II, office 112 Vereyskaya str.  
17 121357 Moscow, Russia  
MAIL: Sales.IA.RU@deltaww.com

**Delta Greentech Elektronik San. Ltd. Sti. (Turkiye)**  
Serifali Mah. Hendem Cad. Kule Sok. No: 16-A  
34775 Umraniye / Istanbul  
MAIL: Sales.IA.Turkey@deltaww.com

**Delta Energy Systems AG (Dubai BR)**  
P.O. Box 185668, Gate 7, 3rd Floor, Hamarain Centre,  
Dubai, United Arab Emirates  
MAIL: Sales.IA.MEA@deltaww.com



# DPMSoft User Manual

[www.deltaww.com](http://www.deltaww.com)

\*We reserve the right to change the information in this catalogue without prior notice.

2018/12/12



# DPMSoft User Manual

## Revision History

Version	Revision	Date
1 <sup>st</sup>	The first version was published.	2018/12/12

**DPMSoft User Manual**  
**Contents**

**Chapter 1 Introduction to DPMSoft**

<b>1.1 Overview .....</b>	<b>2</b>
<b>1.2 Install DPMSoft .....</b>	<b>2</b>
<b>1.3 Uninstall DPMSoft.....</b>	<b>5</b>

**Chapter 2 DPMSoft Connections**

<b>2.1 Serial Port Communication Settings .....</b>	<b>2</b>
<b>2.2 TCP/IP Network Connections .....</b>	<b>4</b>

**Chapter 3 DPMSoft Screen Display**

<b>3.1 Information.....</b>	<b>2</b>
<b>3.2 Voltage.....</b>	<b>3</b>
<b>3.3 Current.....</b>	<b>3</b>
<b>3.4 Power Factor .....</b>	<b>4</b>
<b>3.5 Power.....</b>	<b>4</b>
<b>3.6 Energy.....</b>	<b>5</b>
<b>3.7 Total Harmonic Distortion (THD) .....</b>	<b>5</b>
<b>3.8 Demand.....</b>	<b>6</b>
<b>3.9 Maximum .....</b>	<b>6</b>
<b>3.10 Minimum .....</b>	<b>7</b>
<b>3.11 Alarm .....</b>	<b>7</b>
<b>3.12 Group .....</b>	<b>8</b>
<b>3.13 Alarm History .....</b>	<b>17</b>
<b>3.14 Tariff .....</b>	<b>17</b>

**Chapter 4 DPMSoft Settings**

**4.1 System Setting..... 2**

**4.2 Advance Setting ..... 22**

**4.3 Data Log..... 35**

---


# Chapter 1 Introduction to DPMSoft

## Table of Contents

- 1.1 Overview ..... 2
- 1.2 Install DPMSoft ..... 2
- 1.3 Uninstall DPMSoft..... 5

## 1.1 Overview

DPMSOft is a software designed to read data from Delta power meters and complete setups including communications, current transformers (CT) and alarms. In addition, DPMSOft supports advanced functions of power meter DPM Series, such as auto recording, data storage as well as data import and export.



## 1.2 Install DPMSOft


Download DPMSOft via Delta Electronics official website: <http://www.deltaww.com/>

Software Info:


Operating system (Windows 7/8/10)

Steps to installing DPMSOft:


- (1) Open the compressed file and double click "DPMSOftSetup.msi" for installation.



- (2) Click "Next" when entering the DPMSoft setup page (see below).




- (3) Click "Browse" to select a location for the installation folder and click "Next" to continue the process.




(4) After confirming the installation directory, click "Next" to start the installation.

1




(5) A single bar diagram for installing DPMSOft is shown on the page.






- (6) When DPMSoft installation is complete, click "Close" to exit the process.



- (7) After installation, click the desktop or system shortcut for DPMSoft to enable the software. In addition, users can view multiple windows on the power meter via clicking the DPMSoft shortcut icon.




### 1.3 Uninstall DPMSoft

Steps to uninstall DPMSoft:

Enter 'Control Panel' and select **DPMSoftSetup** listed in the 'Uninstall or change a program' page to remove the software.

1



---


# Chapter 2 DPMSoft Connections

## Table of Contents

2.1 Serial Port Communication Settings ..... 2


2.2 TCP/IP Network Connections ..... 4

Double click the installed DPMSOft icon and a pop-up window for connection will appear. There are two methods for connecting the DPMSOft to the power meter; one is serial port communication (see bottom left) and the other is TCP/IP network connections (see bottom right).



## 2.1 Serial Port Communication Settings

- **Steps to set up serial port communication:**
  - (1) Select a COM Port.



- (2) Input the slave station, communication mode, Baud rate, data bit, parity, stop bit of the power meter. Enter the required timeout (ms) and the command speed for DPMSOft.


Communication Mode: RTU/ ASCII

Baud Rate: 9600/ 19200/ 38400


Parity: NONE/ EVEN/ ODD

Data Bit: 7/ 8

Stop Bit: 1/ 2




- (3) After the setup, connect to the power meter by clicking 'Connect'. For successful connection, the DPMSOft main page window will pop-up; for unsuccessful connection, a pop-up window will appear to point out the connection failure.




## 2.2 TCP/IP Network Connections

- **Steps to set up TCP/IP Network Connections:**
  - (1) Setup the IP address and station of the power meter. When the RS-485 is used to communicate between the power meter and Ethernet converter, enter the IP address and station of the router. Users also need to type in the required timeout (ms) and choose the command speed of the DPMSOft.


2



- (2) When setup is complete, connect to the power meter by clicking 'Connect'. For successful connection, the DPMSOft main page window will pop-up; for unsuccessful connection, a pop-up window will appear to point out the connection failure.



The DPMSOft main page window (see below) pops-up when connection is successful.



**MEMO**




---

# Chapter 3 DPMSoft Screen Display

## Table of Contents

- 3.1 Information..... 2
- 3.2 Voltage..... 3
- 3.3 Current..... 3
- 3.4 Power Factor ..... 4
- 3.5 Power ..... 4
- 3.6 Energy..... 5
- 3.7 Total Harmonic Distortion (THD) ..... 5
- 3.8 Demand..... 6
- 3.9 Maximum ..... 6
- 3.10 Minimum ..... 7
- 3.11 Alarm ..... 7
- 3.12 Group ..... 8
- 3.13 Alarm History ..... 17
- 3.14 Tariff ..... 17


When DPMSOft and the Delta power meter is successfully connected, the software interface displays the language such as English, Traditional Chinese or Simplified Chinese base on the Windows system. To change the displayed language, select the Language menu on the upper right corner of the page and choose the desired language.



The DPMSOft screen displays including Information, Voltage, Current, Power Factor, Power, Energy, Total Harmonic Distortion (THD), Demand, Maximum, Minimum, Alarm, Group, Alarm History and Tariff with explanations in the following sections.

### 3.1 Information


The page displays most commonly used parameters for measurements including voltage, neutral voltage, current, active power, reactive power, apparent power, active energy, power factor as well as voltage and current total harmonic distortions.



## 3.2 Voltage

The page displays the average voltage and voltage per phase, voltage unbalance rate as well as the average, phase to phase and unbalance rate value of line voltage.

- Click the button on the left → select Voltage to enter the page (see below).




Index	Name	Description	Value	Unit	Register
1	Van	Voltage A-N	0	V	100H, 101H
2	Vbn	Voltage B-N	0	V	102H, 103H
3	Vcn	Voltage C-N	0	V	104H, 105H
4	Vavg	Voltage L-N Avg	0	V	106H, 107H
5	Vab	Voltage A-B	0	V	108H, 109H
6	Vbc	Voltage B-C	0	V	10AH, 10BH
7	Vca	Voltage C-A	0	V	10CH, 10DH
8	Vavg	Voltage L-L Avg	0	V	10EH, 10FH
9	Vun	Voltage Unbalance A-N	0	%	110H, 111H
10	Vbn	Voltage Unbalance B-N	0	%	112H, 113H
11	Vcn	Voltage Unbalance C-N	0	%	114H, 115H
12	Vtot	Voltage Unbalance L-N ...	0	%	116H, 117H
13	Vab	Voltage Unbalance A-B	0	%	118H, 119H
14	Vbc	Voltage Unbalance B-C	0	%	11AH, 11BH
15	Vca	Voltage Unbalance C-A	0	%	11CH, 11DH
16	Vtot	Voltage Unbalance L-L ...	0	%	11EH, 11FH

## 3.3 Current

The page displays current, current unbalance rate value.

- Click the button on the left → select Current to enter the page (see below).




Index	Name	Description	Value	Unit	Register
1	Ia	Current A	0	A	120H, 121H
2	Ib	Current B	0	A	122H, 123H
3	Ic	Current C	0	A	124H, 125H
4	Iavg	Current Avg	0	A	126H, 127H
5	In	Current N	0	A	128H, 129H
6	Ia	Current Unbalance A	0	%	12AH, 12BH
7	Ib	Current Unbalance B	0	%	12CH, 12DH
8	Ic	Current Unbalance C	0	%	12EH, 12FH
9	Itot	Current Unbalance Worst	0	%	130H, 131H

### 3.4 Power Factor

The page displays power factor and displacement power factor per phase and in total.


- Click the button on the left → select Power Factor to enter the page (see below).



### 3.5 Power

The page displays the active power, reactive power per phase and apparent power per phase and in total.


- Click the button on the left → select Power to enter the page (see below).



### 3.6 Energy

The page displays active, reactive and apparent energy delivered or received, automated energy recording as well as displacement energy values.

- Click the button on the left → select Energy to enter the page (see below).




Index	Name	Description	Value	Unit	Register
1	E+	Active Energy Delivered	1000.005	kWh	15CH, 15DH
2	E-	Active Energy Received	0	kWh	15EH, 15FH
3	E+	Reactive Energy Delivered	0	kVARh	160H, 161H
4	E-	Reactive Energy Received	0	kVARh	162H, 163H
5	E+	Apparent Energy Delivered	0	kVAh	164H, 165H
6	E-	Apparent Energy Received	0	kVAh	166H, 167H
7	E+ + E-	Active Energy Delivered ...	1000.005	kWh	168H, 169H
8	E+ - E-	Active Energy Delivered ...	1000.005	kWh	16AH, 16BH
9	E+ + E+	Reactive Energy Delivered ...	0	kVARh	16CH, 16DH
10	E+ - E+	Reactive Energy Delivered ...	0	kVARh	16EH, 16FH
11	E+ + E-	Apparent Energy Delivered ...	0	kVAh	170H, 171H
12	E+ - E-	Apparent Energy Delivered ...	0	kVAh	172H, 173H
13	D01	Demand Use Intensity	0	kWm2	18CH, 18DH
14	EUI	Energy Use Intensity	0.015	kWh/m2	18EH, 18FH
15	E+ _1	Automatic Active Energy...	0	kWh	1C0H, 1C1H
16	E- _1	Automatic Active Energy...	0	kWh	1C2H, 1C3H
17	E+ _2	Automatic Active Energy...	0	kWh	1C4H, 1C5H
18	E- _2	Automatic Active Energy...	0	kWh	1C6H, 1C7H
19	E+ _1	Automatic Reactive Ener...	0	VARh	1C8H, 1C9H
20	E- _1	Automatic Reactive Ener...	0	VARh	1CAH, 1CBH
21	E+ _2	Automatic Reactive Ener...	0	VARh	1CCH, 1CDH
22	E- _2	Automatic Reactive Ener...	0	VARh	1CEH, 1CFH

### 3.7 Total Harmonic Distortion (THD)

The page displays voltage and current THD or THD per phase, 1st to 31st voltage harmonic values.

- Click the button on the left → select THD to enter the page (see below).




Index	Name	Description	Value	Unit	Register
1		THD Current A	0	%	174H, 175H
2		THD Current B	0	%	176H, 177H
3		THD Current C	0	%	178H, 179H
4		THD Current N	0	%	17AH, 17BH
5		THD Voltage A-N	0	%	17CH, 17DH
6		THD Voltage B-N	0	%	17EH, 17FH
7		THD Voltage C-N	0	%	180H, 181H
8		THD Voltage A-EI	NaN	%	182H, 183H
9		THD Voltage B-C	NaN	%	184H, 185H
10		THD Voltage C-A	NaN	%	186H, 187H
11		Current THD	0	%	188H, 189H
12		Voltage THD	0	%	18AH, 18BH
13		1st voltage harmonic of ...	0	%	0700H
14		2nd voltage harmonic of ...	0	%	0700H
15		3rd voltage harmonic of ...	0	%	0700H
16		4th voltage harmonic of ...	0	%	0700H
17		5th voltage harmonic of ...	0	%	0700H
18		6th voltage harmonic of ...	0	%	0700H
19		7th voltage harmonic of ...	0	%	0700H
20		8th voltage harmonic of ...	0	%	0700H
21		9th voltage harmonic of ...	0	%	0700H
22		10th voltage harmonic of ...	0	%	0700H

### 3.8 Demand

The page displays the present, last and next Current demand value. The list also shows the peak value and its occurring date and time.


- Click the button on the left → select Demand to enter the page (see below).



### 3.9 Maximum

The page displays the maximum values, date and time of parameters.

- Click the button on the left → select Maximum to enter the page (see below).



### 3.10 Minimum

The page displays the minimum values, date and time of parameters.

- Click the button on the left → select Minimum to enter the page (see below).

Index	Name	Description	Date	Time	Value	Unit	Register
1	Vab Min	Line Voltage A-B...	1999/01/01	00:00:00	100000	Y	300H ~ 305H
2	Vbc Min	Line Voltage B-C...	1999/01/01	00:00:00	100000	Y	306H ~ 308H
3	Vca Min	Line Voltage C-A...	1999/01/01	00:00:00	100000	Y	309H ~ 311H
4	Vaa Min	Phase Voltage A...	1999/01/01	00:00:00	100000	Y	312H ~ 317H
5	Vba Min	Phase Voltage B...	1999/01/01	00:00:00	100000	Y	318H ~ 319H
6	Vca Min	Phase Voltage C...	1999/01/01	00:00:00	100000	Y	319H ~ 323H
7	Ia Min	Current Ia Min...	1999/01/01	00:00:00	100000	A	324H ~ 329H
8	Ib Min	Current Ib Min...	1999/01/01	00:00:00	100000	A	329H ~ 332H
9	Ic Min	Current Ic Min...	1999/01/01	00:00:00	100000	A	333H ~ 335H
10	In Min	Current In Min...	1999/01/01	00:00:00	100000	A	336H ~ 338H
11	Freq Min	Frequency Min...	1999/01/01	00:00:00	100	Hz	339H ~ 341H
12	PPFot Min	Power Factor Min...	1999/01/01	00:00:00	10		342H ~ 347H
13	Ptot Min	Active Power Tot...	1999/01/01	00:00:00	100000	kW	348H ~ 349H
14	Qtot Min	Reactive Power T...	1999/01/01	00:00:00	100000	kVAR	349H ~ 353H
15	Stot Min	Apparent Power ...	1999/01/01	00:00:00	100000	kVA	354H ~ 359H
16	Vab THD Min	Line Voltage A-B...	1999/01/01	NaN	NaN	%	359H ~ 365H
17	Vbc THD Min	Line Voltage B-C...	1999/01/01	NaN	NaN	%	366H ~ 368H
18	Vca THD Min	Line Voltage C-A...	1999/01/01	NaN	NaN	%	369H ~ 373H
19	Vaa THD Min	Phase Voltage A...	1999/01/01	00:00:00	999.999	%	374H ~ 379H
20	Vba THD Min	Phase Voltage B...	1999/01/01	00:00:00	999.999	%	380H ~ 385H
21	Vca THD Min	Phase Voltage C...	1999/01/01	00:00:00	999.999	%	386H ~ 391H
22	VLL THD Min	Line Voltage TH...	1999/01/01	NaN	NaN	%	392H ~ 393H

### 3.11 Alarm

The page displays the current alarm status, the number of alarm events as well as time and date. If the alarm is deactivated, the page background color is green; however, if the alarm is activated, the background color turns red.


- Click the button on the left → select Alarm to enter the page (see below).

Index	Name	Description	Date	Time	Value	Unit	Register
1		Over Current Ala...	1999/01/01	00:00:00	0		400H ~ 405H
2		Under Current AL...	1999/01/01	00:00:00	0		406H ~ 408H
3		Over Neutral Cur...	1999/01/01	00:00:00	0		409H ~ 411H
4		Over Line Voltag...	1999/01/01	00:00:00	0		412H ~ 417H
5		Under Line Volta...	1999/01/01	00:00:00	0		418H ~ 419H
6		Over Phase Volta...	1999/01/01	00:00:00	0		419H ~ 423H
7		Under Phase Volt...	1999/01/01	00:00:00	0		424H ~ 429H
8		Over Volt Unbala...	1999/01/01	00:00:00	0		429H ~ 432H
9		Over Amp Unbal...	1999/01/01	00:00:00	0		433H ~ 435H
10		Over Active Pow...	1999/01/01	00:00:00	0		436H ~ 438H
11		Over Reactive Po...	1999/01/01	00:00:00	0		439H ~ 441H
12		Over Apparent P...	1999/01/01	00:00:00	0		442H ~ 447H
13		Lead PF Alarm St...	1999/01/01	00:00:00	0		448H ~ 449H
14		Lag PF Alarm Sta...	1999/01/01	00:00:00	0		450H ~ 453H
15		Lead DFF Alarm ...	1999/01/01	00:00:00	0		454H ~ 459H
16		Lag DFF Alarm S...	1999/01/01	00:00:00	0		460H ~ 465H
17		Over Current Dem...	1999/01/01	00:00:00	0		466H ~ 468H
18		Over kW Deman...	1999/01/01	00:00:00	0		469H ~ 473H
19		Over kVAR Dema...	1999/01/01	00:00:00	0		474H ~ 479H
20		Over kVA Dema...	1999/01/01	00:00:00	0		480H ~ 485H
21		Over Frequency ...	1999/01/01	00:00:00	0		486H ~ 491H
22		Under Frequency...	1999/01/01	00:00:00	0		492H ~ 493H

### 3.12 Group


The page displays the mapping value regarding the group parameter setting.

- Click the button on the left → select Group to enter the page (see below).




The Group page contains three useful buttons including “Group Set” , “Import” and “Export” with the following explanations.

- Group Set:** The button displays the parameter data for setup through the following steps:
  - First, select the parameters displayed on the page.







- (2) Click "Group Set" to start the process after selecting the parameters.




- (3) When the setup is complete, a pop-up window will appear to show the setting is successful, click OK to view the selected parameter data on the page.






- **Export:** The button exports large number of parameters through the following steps.


- (1) Select the parameters and click 'Export' button.




- (2) After clicking the 'Export' button, a pop-up window for file saving appears. Users need to choose the appropriate directory and click 'Save' to start the process.




- (3) A pop-up window appears when the group data export is a success. Click OK and the export file can be viewed from the desktop.






(4) Open the ExportGroup.xls from the desktop (see below).



Description on exporting files: Below, the blue frame on the left are the group parameters for import, while the green frame on the right provides parameter codes for reference.




## Parameter Code List:


Code	Parameter	Code	Parameter
0	None	31	Displacement Power Factor A
1	Voltage A	32	Displacement Power Factor B
2	Voltage B	33	Displacement Power Factor C
3	Voltage C	34	Frequency
4	Voltage Average	35	Power Factor Total
5	Voltage A-B	36	Active Power Factor A
6	Voltage B-C	37	Active Power Factor B
7	Voltage C-A	38	Active Power Factor C
8	Line Voltage Balance	39	Reactive Power Factor Total
9	Voltage Unbalance A	40	Reactive Power Factor A
10	Voltage Unbalance B	41	Reactive Power Factor B
11	Voltage Unbalance C	42	Reactive Power Factor C
12	Phase Voltage Unbalance	43	Apparent Power Total
13	Voltage Unbalance A-B	44	Apparent Power A
14	Voltage Unbalance B-C	45	Apparent Power B
15	Voltage Unbalance C-A	46	Apparent Power C
16	Line Voltage Unbalance	47	Active Energy Delivered
17	Current A	48	Active Energy Received
18	Current B	49	Reactive Energy Delivered
19	Current C	50	Reactive Energy Received
20	Average Current	51	Apparent Energy Delivered
21	Current N	52	Apparent Energy Received
22	Current Unbalance A	53	Active Energy Delivered + Reactive Energy Delivered
23	Current Unbalance B	54	Active Energy Delivered - Reactive Energy Delivered
24	Current Unbalance C	55	Active Energy Received + Reactive Energy Received
25	Three-Phase Current Unbalance	56	Active Energy Received - Reactive Energy Received
26	Power Factor Total	57	Apparent Energy Delivered + Apparent Energy Received
27	Power Factor A	58	Apparent Energy Delivered - Apparent Energy Received
28	Power Factor B	59	THD Current A
29	Power Factor C	60	THD Current B
30	Displacement Power Factor Total	61	THD Current C

Code	Parameter	Code	Parameter
62	THD Current N	90	Last Apparent Power Demand
63	THD Voltage A	91	Next Apparent Power Demand
64	THD Voltage B	92	Apparent Power Demand Peak
65	THD Voltage C	93	Apparent Power Demand Peak Date
66	THD Voltage A-B	94	Apparent Power Demand Peak Time
67	THD Voltage B-C	95	Energy Demand Intensity
68	THD Voltage C-A	96	Energy Use Intensity
69	Total Current THD	97	Auto Recording Active Power 1
70	Total Voltage THD	98	Auto Recording Reactive Power 1
71	Present Current Demand	99	Auto Recording Active Power 2
72	Last Current Demand	100	Auto Recording Reactive Power 2
73	Next Current Demand	101	Auto Recording Reactive Energy Delivered 1
74	Current Demand Peak	102	Auto Recording Reactive Energy Received 1
75	Current Demand Peak Date	103	Auto Recording Reactive Energy Delivered 2
76	Current Demand Peak Time	104	Auto Recording Reactive Energy Received 2
77	Current Active Power Demand	105	Total Instantaneous Active Power
78	Last Active Power Demand	106	Instantaneous Active Power A
79	Next Active Power Demand	107	Instantaneous Active Power B
80	Active Power Demand Peak	108	Instantaneous Active Power C
81	Active Power Demand Peak Date	109	Total Instantaneous Reactive Power
82	Active Power Demand Peak Time	110	Instantaneous Reactive Power A
83	Current Reactive Power Demand	111	Instantaneous Reactive Power B
84	Last Reactive Power Demand	112	Instantaneous Reactive Power C
85	Next Reactive Power Demand	113	Total Instantaneous Apparent Power
86	Reactive Power Demand Peak	114	Instantaneous Apparent Power A
87	Reactive Power Demand Peak Date	115	Instantaneous Apparent Power B
88	Reactive Power Demand Peak Time	116	Instantaneous Apparent Power C
89	Current Apparent Power Demand		



- **Import:** The button imports excel files and large number of parameters through the following steps.
  - (1) Click 'Import' and a pop-up window will appear for users to choose and open the selected file.



- (2) The import process for the selected excel file starts and a diagram showing the current import progress will appear.



- (3) A pop-up window appears when the imported group parameter is a success. Click OK and the selected parameter data can be viewed from the desktop.






### 3.13 Alarm History

The page displays the mapping value regarding the group parameter setting.


- Click the button on the left → select Alarm History to enter the page (see below).



### 3.14 Tariff

The page displays the tariff point (P1), peak (P2), plateau (P3), valley (P4) for power usage as well on hourly basis daily.

- Click the button on the left → select Tariff to enter the page (see below).



**MEMO**

---

# Chapter 4 DPMSoft Settings

## Table of Contents


4.1 System Setting ..... 2

4.2 Advance Setting ..... 22


4.3 Data Log ..... 35

DPMSOft contains options including System Setting, Advanced Setting and Data Log for power meter setup with the following explanations.

## 4.1 System Setting




- 1. Meter Information:**  
Displays including meter model name, firmware version, date and operation time.




## 2. Transformer Ratio:


Provides CT Primary, CT Secondary, PT Primary and PT Secondary setups.



- CT Primary: Set the primary CT within the range of 1 to 9999 A.
- CT Secondary: Set the secondary CT within the available options of 1A, 5A and 2.5A.
- PT Primary: Set the primary PT within the range of 1 to 99999 V.
- PT Secondary: Set the secondary PT within the range of 1 ~ 9999 V.


Click "Transformer Set" when the setting is complete and a pop-up window appears showing whether the setting is successful or not.






3. System:


Provides setups for user interface regarding the power meter and parameters on wiring.




- Language: The display language on the user interface of the power meter include English, Traditional Chinese and Simplified Chinese.
- Backlight: The brightness of the screen backlight includes 25%, 50% and 100%.
- Timeout: When the user do not press the button on the power meter during the timeout, the brightness of the screen backlight is based on the previous percentage setup, but when the button is pressed, the brightness of the screen backlight is 100%.
- Power System: Supports power wiring including 3P4W, 3P3W, 1P2W and 1P3W.
- Rotation: When current A and C are incorrectly wired, set the rotation parameter and rewire is not necessary.
- Transformer Number: The number of CT & PT used in the system.

Click “System Set” when the setup is complete and a pop-up window appears showing whether the setting is successful or not.





**4. Alarm:**  
Setup the alarm parameters for the power meter.




- Dropdown Menu: Select a required alarm from 29 alarm types.
- Alarm Enable: Choose  to enable or  to disable the alarm.
- Pickup: When higher than the pickup current, the alarm is enabled
- Time Delay: When higher than the pickup current and exceeds the time delay, the alarm is enabled.




- Dropout: When lower than the drop-out current, the alarm is disabled.
- Time Delay: When lower than the drop-out current and exceeds the time delay, the alarm is disabled.

Steps to setting the alarm:

- (1) Select an alarm type.



- (2) Click "Alarm Enable".



- (3) Select the Pickup value and Time Delay.

The screenshot shows the 'Alarm' configuration window. At the top, there is a dropdown menu set to 'Over Current'. Below it is a checked checkbox for 'Alarm Enable'. There are four input fields: 'Pickup' with the value '10.0', 'Time Delay' with the value '1', 'Dropout' with the value '1.0', and another 'Time Delay' with the value '1'. The 'Pickup' and the first 'Time Delay' fields are highlighted with a red rectangular box. At the bottom of the window is a button labeled 'Alarm Set'.


(4) Select the Drop-out value and Time Delay.

The screenshot shows the 'Alarm' configuration window. The 'Pickup' and the first 'Time Delay' fields are now set to '10.0' and '1' respectively. The 'Dropout' and the second 'Time Delay' fields are highlighted with a red rectangular box. The 'Dropout' field contains the value '1.0' and the second 'Time Delay' field contains the value '1'. The 'Alarm Set' button is at the bottom.

Click "Alarm Set" when the setting is complete and a pop-up window appears showing whether the setting is successful or not.

(5)


The screenshot shows the 'Alarm' configuration window. All four input fields are now set to their final values: 'Pickup' is '10.0', the first 'Time Delay' is '1', 'Dropout' is '1.0', and the second 'Time Delay' is '1'. The 'Alarm Set' button at the bottom is highlighted with a red rectangular box.



(6) Repeat steps (1) ~ (5) for settings regarding all the other 28 alarm types.



**5. Communications:**

Setup the communications parameters for the power meter.




- Station: Modbus slave station ranges from 1~254. When using BACnet MS/TP as communication mode, the MAC ID ranges from 1~127.
- Mode: Supports RS-485, Modbus ASCII / RTU and BACnet MS/TP.
- Baud Rate: For RS-485, communication speed supports 9600, 19200 or 38400 bps. If the mode is BACnet MS/TP, the default setting speed is 38400 bps.
- Data bit: Supports 7-bit or 8-bit data.
- Parity: The parity bit for RS485 communications include None, Odd or Even.
- Stop bit: Supports 1 or 2 bit to indicate the end of data transmission.

Click "Communication Set" when the setting is complete and a pop-up window appears showing whether the setting is successful or not.




## 6. Date:


Provides date and time parameters for power meter setup.



- Auto: Automatically sets the date and time based on the PC, no manual setting required.
- Manual: Manually select the time and date


Click "Date Time Set" when the setting is complete and a pop-up window appears showing whether the setting is successful or not.






7. Demand:

Setup methods for measuring power meter' s demand.




- Method: Currently supports Time Block for measuring power meter' s demands.
- Interval: Supports demand measuring interval time ranging from 1 to 60 min.

Click "Demand Set" when the setting is complete and a pop-up window appears showing whether the setting is successful or not.




4




**8. Meter Reset:**


Provides parameters regarding power meter reset.




Click "Reset Set" when the setting is complete and a pop-up window appears showing whether the setting is successful or not.







9. **BACnet Device ID :**  
Setup the parameter for BACnet ID.




- BACnet Device ID: The device identifier in BACnet MS/TP include 0 ~ 4194303.
- Station: The MAC ID supports 1 ~ 127 stations for BACnet MS/TP mode.
- Baud Rate: For RS485 communications, the baud rate supports 9600, 19200 or 38400 bps. If the setup is BACnet MS/TP mode, the default setting is 38400 bps.


- Data bit: Supports 7-bit or 8-bit data. For BACnet MS/TP mode, the default setting is 8 bit.
- Parity: The parity bit for RS485 communications include None, Odd or Even. For BACnet MS/TP mode, the default setting is None.
- Stop bit: Supports 1 or 2 bit to indicate the end of data transmission. For BACnet MS/TP mode, the default setting is 1 bit.

※Note:

- a.) Switch to BACnet MS/TP mode, the baud rate, data bit, parity and stop bit automatically change to its default setting in the order of 38400 bps, 8 bit, None and 1 bit.
- b.) The BACnet MS/TP MAC ID and Modbus slave station shares the same parameter.


Click “BACnet Set” when the setting is complete and a pop-up window appears showing whether the setting is successful or not.






※ **Note:** The system setting page differs based on the power meter type and together the displayed setting blocks is also different. The setting page for DPM-C520W and DPM-C501L are described below.

■ **DPM-C520W System Setting Page:**




The difference regarding the setting page of a standard DPMSOft and DPM-C520W connecting to DPMSOft is that a BACnet ID setting box is presented with router connection setups on the bottom right of the page, but this setting is not available for standard DPMSOft page.




- SSID: Type the SSID name that connects the DPM-C520W to a router. The naming format is WiFi\_Modbus\_00X, the X differs based on the third digit box in the IP address.
- Password: The fixed password for connecting DPM-C520W to a router is 1234567890.
- IP Address: The IP for DPM-C520W is fixed, but the third digit box varies according to the domains, while the fourth digit box refers to the power meter station.
- Subnet Mask: Fixed as 255.255.255.0


When the setup for the third digit box is complete, the SSID will also change accordingly ( see below):




Click "Connection Set" when the connection settings for the router is complete and a pop-up window appears showing whether the setting is successful or not.




4




■ **DPM-C501L System Setting Page:**



The difference regarding the setting page of a standard DPMSOft and C501L connecting to DPMSOft is that a DIDO setting box is presented on the bottom right of the page, but this setting is not available for standard DPMSOft page.




- Enable DI1~DI4: To enable or disable digital input function.
- Relay1~Relay4 Output: A high signal appears when DI enables or an alarm occurs.




- DI1~DI4: DI status.
- DO1~DO2 Status: The DO status shows lights off for open circuit, lights on for short circuit. Select 'Com' in 'Relay Output' drop-list first or the following error window will appear.


4



Methods for relay control setting via computers:  
 Select Com for Relay1 Output or Relay2 Out, then click "DIDO Set".




## 4.2 Advance Setting






1. **Auto Recording:**  
Auto recording monthly power usage.




- Auto Recording1 Enable: Choose  to enable or  to disable auto recording1.
- Recording Day: Select a day to measure monthly power usage regarding group1.
- Auto Recording2 Enable: Choose  to enable or  to disable auto recording2.
- Recording Day: Select a day to measure monthly power usage regarding group2.

Steps for auto recording:

- (1) Choose a day (1~31) every month to start recording.



- (2) Click "Auto Recording1 Enable" and choose "Auto Recording 1 Set" (see below) to start auto recording 1.




(3) Repeat the same steps (1) ~ (2) for setting Auto Recording2.

※ Note:

- a.) If the setting day exceeds the last day of that month, use the last day of that month instead.
- b.) Calculation: Assume the calculation starts from on the 1st of this month, 0 hr 0 min 0 sec and record the data to the last day of this month, 23 hr 59 min 59 sec. (The end day of the month varies and is set on the 28th, 30th or 31st based on the month.)

**2. Auto Max and Min Interval Reset**




Provides auto reset for maximum and minimum interval setting.



- Auto Reset Max and Min Interval: The software automatically reset the maximum and minimum interval base on a specific period (per day, month or year).


Item	Function Description
Disable	Close the function, manual reset required
Day	Reset daily
Month	Resets on the first day of every month
Year	Resets on the first of January every year

When setups for auto reset maximum and minimum interval is complete, a pop-up window will show whether the setting is successful or not.




### 3. Energy Use Intensity (EUI):

Calculate the EUI via using its formula: kWh / Area (m<sup>2</sup>). The calculated value expresses the energy utility consumed per square feet of conditioned space.




- Floor Area: Square feet of the building interior space

When parameter settings for floor area is complete, click "Area Set" and a pop-up window appears showing whether the setting is successful or not.



#### 4. Energy Saving:



The current accumulated energy is categorized into normal or energy saving mode.





- Enable Energy Saving: Select  to enable or  to close energy saving / non-energy saving mode.
- Normal / Energy Saving Mode: Switch the accumulated energy to either energy saving or non-energy saving mode.

The following steps describe the energy saving mode settings:

- (1) Choose "Enable Energy Saving" and "Energy Saving Mode". Then, click "Energy Saving Set" to enable this function.




- Choose "Normal Mode" and click "Energy Saving Set" to switch the accumulated energy to normal mode.






5. **Tariff:**  
Record energy base on the off-peak times.




- Type: Select from the 4 types of tariff during a day including point (P1), peak (P2), plateau (P3) or valley (P4).
- Start Time: The starting time to record accumulated energy
- End Time: The ending time to record accumulated energy.


The following steps describe the tariff settings:

- (1) Select the desired "point (P1), peak (P2), plateau (P3) or valley (P4)" and setup the start and end time.




- (2) Repeat step (1) regarding tariff setups for the 2nd to 8th group.
- (3) When the setups are complete, click "Tariff Set" .






※ Note:

- a.) When the start and end time are set to be the same, the tariff function is disabled.
- b.) If the start time exceeds the end time (see below), this means the tariff is calculated till the next day.





**6. Every Day Every Hour Energy Record:**  
Record the hour-by-hour accumulated energy in a day.



- Every Day Every Hour Energy Record Enable: Choose  to enable or  to close the function.


When the “Every Day Every Hour Energy Record” is enabled, click “Tariff Set” and a pop-up window appears showing whether the setting is successful or not.





### 4.3 Data Log

Store the logs regarding parameters in the non-volatile memory (NVM) and download the data logs via RS-485 communications.




- Start Date Time: The time and date to enable data log.
- Interval: Record the interval of the power meter, with the minimum interval as 0 (min) : 5 (sec), the maximum interval as 60 (min) : 0 (sec). If the interval is set as 0 (min) : 0 (sec), this means the interval function is disabled.

- Read and Save: The exported logs are in CSV format and select a download location.
- Data Log Setting 01~17: Choose from up to 17 content parameters and sequence for data storage.
- Data Log Specification:


Interval	0 min 0 sec ~ 0 min 59 sec	1 min 0sec ~ 4 min 59 sec	5 min 0 sec ~ 60 min 0 sec
Item			
Maximum Parameters (number)	6	17	17
Maximum Capacity (Day)	7	31	62

Setup data log through the following steps:


- (1) Select the desired parameters in the order 01 to 17 from the data log setting section and base on the above specifications for data storage.




- (2) Click "Set Data Log Setting" (see below) to complete the setting.




- (3) Select the desired data log interval.



- (4) Click "Store Interval Set" to complete the setting.




- (5) To download the data log onto the PC, click "Read and Save" .






- (6) Choose the data log file and download location, then click “Save”.



- (7) The sentence “Save Data Log Success” appears at the bottom of the page when the download is complete.




※ **Note :**


- a.) First complete the "Data Log Setting 01~17" to setup the sequence and then select the "Interval" . If "Interval" is set first, then "Data Store Setting 01~17" cannot be setup. ( " Set Data Log Setting" button cannot be clicked )
- b.) When the data store setting exceeds the specification, the exceeding content is ignored. In other words, if the interval is set at 5 sec, the data store setting from 07 and more are automatically ignored.

※ **Modify Setups:**


- (1) When the interval is set at 5 sec and the "Set Data Log Setting" clicked, a pop-up window appears pointing out the data log interval need to be set as 0:00 first to correctly set up the data log.




- (2) Therefore, the “Interval” is set as 0 min 0 sec (disable the function) then click “Set Data Log Setting” .



- (3) When step (2) is complete, users can modify the data log setting section (01~17) and click “Set Data Log Setting” .



(4) When "Interval" is set, click "Store Interval Set" .



4