

Ruijie RG-WS6008 Series Wireless Controller

Hardware Installation and Reference Guide

Document Version: V1.5

Date: December 4, 2024

Copyright © 2024 Ruijie Networks

Copyright

Copyright © 2024 Ruijie Networks

All rights are reserved in this document and this statement.

Without the prior written consent of Ruijie Networks, no organization or individual is permitted to reproduce, extract, back up, modify, or distribute the content of this document in any manner or form. It is also prohibited to translate the document into other languages or use any or all parts of it for commercial purposes.



Ruijie Networks.

All other trademarks or registered trademarks mentioned in this document are owned by their respective owner.

Disclaimer

The products, services, or features that you purchase are subject to commercial contracts and terms. It is possible that some or all of the products, services, or features described in this document may not be available for purchase or use. Unless agreed upon otherwise in the contract, Ruijie Networks does not provide any explicit or implicit statements or warranties regarding the content of this document.

The names, links, descriptions, screenshots, and any other information regarding third-party software mentioned in this document are provided for your reference only. Ruijie Networks does not explicitly or implicitly endorse or recommend the use of any third-party software and does not make any assurances or guarantees concerning the applicability, security, or legality of such software. You should choose and use third-party software based on your business requirements and obtain proper authorization. Ruijie Networks assumes no liability for any risks or damages arising from your use of third-party software.

The content of this document is subject to constant change due to product version upgrades or other reasons. Thus, Ruijie Networks reserves the right to modify the content of the document without prior notice or prompt.

This manual serves solely as a user guide. While Ruijie Networks endeavors to ensure the accuracy and reliability of the content when compiling this manual, it does not guarantee that the content of the manual is free of errors or omissions. All information contained in this manual does not constitute any explicit or implicit warranties.

Personal Data Statement

During the operation or troubleshooting of the products, services, or features you have purchased, certain personal data of users may be collected or used. Therefore, it is essential for you to establish and implement appropriate privacy policies, in compliance with the relevant laws and regulations of the applicable countries or regions, to ensure the complete protection of users' personal data.

If Ruijie Networks is involved in this process, we will strictly adhere to the relevant laws and regulations of the applicable countries or regions and take all necessary actions to safeguard users' personal data.

When discarding, reclaiming, or reusing a device, please ensure to back up or clear any stored data to avoid data leakage. For assistance, please contact our after-sales technical support.

Preface

Intended Audience

This document is intended for:

- Network engineers
- Technical support and servicing engineers
- Network administrators

Technical Support

- Ruijie Networks website: https://www.ruijienetworks.com/
- Online support center: https://ruijienetworks.com/support
- Case portal: https://caseportal.ruijienetworks.com
- Community: https://community.ruijienetworks.com
- Email support: service_rj@ruijienetworks.com
- Live chat: https://www.ruijienetworks.com/rita
- Documentation feedback: doc@ruijie.com.cn

Conventions

1. Signs

The signs used in this document are described as follows:



An alert that contains important safety instructions. Before you work on any equipment, be aware of the hazards involved and be familiar with standard practices in case of accidents.

Warning

An alert that calls attention to important rules and information that if not understood or followed can result in data loss or equipment damage.

A Caution

An alert that calls attention to essential information that if not understood or followed can result in function failure or performance degradation.

Note

An alert that contains additional or supplementary information that if not understood or followed will not lead to serious consequences.



Specification

An alert that contains a description of product or version support.

2. Note

The manual offers configuration information (including model, port type and command line interface) for indicative purpose only. In case of any discrepancy or inconsistency between the manual and the actual version, the actual version prevails.

Contents

Preface	I
1 Product Overview	1
1.1 Product Appearance	1
1.2 LED Indicators	1
1.3 Technical Specifications	2
2 Preparation for Installation	5
2.1 Precautions	5
2.2 Preparing Installation Site	5
2.2.1 Temperature and Humidity Requirements	5
2.2.2 Cleanness Requirements	6
2.2.3 Static Discharge Damage Prevention	7
2.2.4 Anti-Interference Requirements	7
2.2.5 Installation Site Requirements	7
2.3 Installation Tools	8
3 Installing Wireless Controller	9
3.1 Installation Flowchart	9
3.2 Mounting Wireless Controller	9
3.2.1 Mounting RG-WS6008 in Cabinet	10
3.2.2 Mounting RG-WS6008 on Workbench	10
3.3 Installing Power Cable	10
3.4 EMS & Secure Grounding	10
3.5 Connecting Console	11
3.6 Verification	11

4 Configuration Guide	13
4.1 Setting up Configuration Environment	13
4.2 Powering on Wireless Controller	15
4.2.1 Verification Before Power-on	15
4.2.2 Power-on	15
4.2.3 Verification After Power-on	15
4.2.4 Startup Process	15
4.3 Configuring Wireless Controller	16
5 Troubleshooting	17
5.1 Power Troubleshooting	17
5.2 System Troubleshooting	17

1 Product Overview


The RG-WS6008 wireless LAN controller is introduced by Ruijie Networks to provide powerful access control capability for medium-large-sized wireless networks.

1.1 Product Appearance

Figure 1-1 Front Panel of RG-WS6008



Figure 1-2 Rear Panel of RG-WS6008





The nameplate is at the bottom of the access controller.

1.2 LED Indicators

LED	State	Meaning
PWR	Off	The power module is NOT in the position or fails.
	Solid green	The power module is operational.
	Blinking green	The system is being initialized.
SYS	Solid green	The initialization process is complete.
	Solid red	The system sends out an alarm.
1-8 Gigabit	Solid green	The copper port is connected at 10/100/1000 Mbps.
copper ports (link/ACT)	Blinking green	The copper port is receiving or transmitting data.
1-8 Gigabit	Solid orange	The copper port is connected at 1000 Mbps.
(speed)	Off	The copper port is connected at 10/100 Mbps.

LED	State	Meaning
7F-8F Gigabit	Solid green	The fiber port is connected.
fiber ports	Blinking green	The fiber port is receiving or transmitting data.

1.3 Technical Specifications

Dimensions and Weight	RG-WS6008
Unit dimensions (W x D x H)	440 mm x 200 mm x 43.6 mm (17.32 in. x 7.87 in. x 1.72 in.)
Shipping dimensions (W x D x H)	560 mm x 470 mm x 380 mm (22.05 in. x 18.5 in. x 14.96 in.)
Rack height	1 RU
Unit weight	2.9 kg (6.39 lbs)
Shipping weight	16.47 kg (36.31 lbs)
Mounting	Workbench-mount
System Specifications	RG-WS6008
Memory	256 GB DRAM
Flash memory	NAND 512 MB, SPI 8 MB
Port Specification	RG-WS6008
Fixed service port	6 x 10/100/1000BASE-T ports 2 x 1GE SFP/RJ45 combo ports.
Fixed management port	1 x RJ45 console port 2 x USB ports
Status LED	SYS: 1 x system status LED PWR: 1 x power LED Speed: 8 x RJ45 port speed LEDs Link/ACT: 8 x RJ45 port Link/Act LEDs 7F and 8F: 2 x SFP/RJ45 combo port LEDs
Button	 1 x Reset button Press the button for shorter than 3 seconds. Then the device restarts. Press the button for longer than 3 seconds. Then the device restores to factory settings. 1 x Power switch button

Power Supply and Consumption	RG-WS6008	
Maximum power consumption	40 W	
Input power supply	1 x 40 W built-in power module	
Power input	100 V AC to 240 V AC, 50 Hz to 60 Hz, 1.5A (max. RMS current)	
Power output	12 V DC, 3.33 A	
Environment and Reliability	RG-WS6008	
	Operating temperature: 0°C to +45°C (32°F to 113°F)	
	Storage temperature: -40°C to +70°C (-40°F to +158°F)	
Temperature	Note: At an altitude in the range of 1,800–3,000 m (5,905.51–9,842.52 ft.), every time the altitude increases by 166 m (544.62 ft.), the maximum temperature decreases by 1°C (1.8°F).	
Altitude	Operating altitude: 0 m to 3,000m (0 ft. to 9,842.52 ft.)	
Ailitude	Storage altitude: 0 m to 3,000m (0 ft. to 9,842.52 ft.)	
Humidity	Operating humidity: 10% RH to 90% RH (non-condensing)	
Training	Storage humidity: 5% RH to 95% RH (non-condensing)	
Fan	Fan speed adjustment	
i ali	Fan fault alarm	
MTBF	400,000 hours (44 years) at the operating temperature of 25°C (77°F)	
Regulatory compliance	RG-WS6008	
LVD	IEC 62368-1	
	EN 62368-1	
	EN 55032	
	EN 55035	
EMC Standard	EN 61000-3-3	
	EN IEC 61000-3-2	
	EN 300 386	

Note

- A combo port consists of an optical port and an electrical port. The optical port and electrical port cannot work at the same time. If one port is enabled, the other is disabled. You can select the port type as required.
- Due to the variety of USB flash drives, not all of them are supported. A USB flash drive with the FAT32 file system format is recommended.

A Caution

Please avoid vibration and shock when moving and using the device.

Warning

- The circuit breaker in the power module cannot be removed.
- This is a Class A product. In a domestic environment, this product may cause radio interference. In this case, users are advised to take proper measures against the interference.

2 Preparation for Installation

2.1 Precautions

The wireless controller acts as a network repeater and its working affects the normal operation of the whole network.

The following suggestions are advised for the installation and use of RG-WS6008:

- Do not place the wireless controller in a damp/wet location. Do not let any liquid enter the chassis.
- Keep the wireless controller far away from the heat source.
- Ensure that the wireless controller is properly grounded.
- Wear an anti-static wrist strap during installation and maintenance.
- Do not wear loose clothes to avoid hooking any parts. Before operation, tighten your band, shawl, and sleeves.
- Put the tools and parts away from where people walk by.
- Use UPS to prevent power failure and other interferences.
- If the clock is not accurate, check whether the clock has been configured. If not, the inaccuracy is likely to
 occur. If the clock has been configured, the inaccuracy may be caused by the battery running out of power.
 In general, the button battery lasts about 10 years.
- To ensure proper operation of the device, store the device in an environment based on the storage temperature or humidity requirements in specifications.

Note

- Misuse of battery may cause damage to the device or hurt to people. Do not replace battery by yourself.
 Instead, contact Ruijie Service Center for the replacement of battery.
- This device is not suitable for use in locations where children are likely to be present.
- If the device has been powered off for over 18 months, power on the device and keep it run for over 24 hours consistently.
- Keep the device within the restricted-access area.
- The device should be installed by professionals or technicians.

2.2 Preparing Installation Site

RG-WS6008 is for indoor use only. To ensure its normal operation and prolong its life span, the installation site should meet the following requirement:

2.2.1 Temperature and Humidity Requirements

To ensure normal operation and service life of the device, maintain appropriate temperature and humidity levels in your equipment room. See Table 2-1. Improper room temperature and humidity can cause damages to the device. High relative humidity may affect insulation materials, resulting in poor insulation and even electrical leakage, and sometimes may lead to change of mechanical properties of materials and corrosion of metal parts.

Low relative humidity may dry and shrink insulation sheets and cause static electricity that can damage the circuitry inside the device. High temperature greatly reduces reliability of the device and shortens its service life.

Table 2-1 Required Temperature and Humidity for the RG-WS6008

Relative Temperature		Relative Humidity	
Long-time Working Condition	Short-time working Condition	Long-time Working Condition	Short-time Working Condition
15°C to 30°C (59°F to 86°F)	0°C to 45°C (32°F to 113°F)	40%~65%	5%~95%

Note

- The ambient temperature and humidity are measured at a point 1.5 meters (4.9 feet) above the ground and 0.4 meters (1.3 feet) before the device when there is no protective board in the front or back of the rack.
- The short-term working condition refers to a period no longer than consecutive 48 hours or accumulated 15 days a year.
- The extreme working condition refers to the temperature and humidity of the machine room where the air conditioner fails for no more than five hours.

2.2.2 Cleanness Requirements

Dust poses a serious threat to device operation. Dust that falls onto the surface of the device can be absorbed onto metal contact points by static electricity, resulting in poor contact. Electrostatic absorption of dust occurs more easily when the relative humidity is low, which may shorten the service life of the device and cause communication failures. Table 2-2 shows the maximum concentration and diameter of dust allowed in the equipment room.

Table 2-2

Maximum Diameter (μm)	0.5	1	3	5
Maximum Content (Number of Particles in one Cubic Meter)	1.4×10 ⁷	7×10 ⁵	2.4×10 ⁵	1.3×10 ⁵

Besides, the contents of salts, acids and sulfides in the air are also strictly limited for the equipment room. These substances can accelerate metal corrosion and the aging of some parts. Table 2-3 describes the limit of some hazardous gases such as SO₂, H₂S, NO₂ and Cl₂ in the equipment room.

Table 2-3

Gas	Average (mg/m³)	Maximum (mg/m³)
SO ₂	0.2	1.5
H ₂ S	0.006	0.03

Gas	Average (mg/m³)	Maximum (mg/m³)
NO ₂	0.04	0.15
NH ₃	0.05	0.15
Cl ₂	0.01	0.3

2.2.3 Static Discharge Damage Prevention

Although much has been done in RG-WS6008 to prevent static electricity, great damage may be caused to the circuitry when the static electricity exceeds a certain limit. Electrostatic induction may come from the following sources:

- External electric field produced by the high-voltage supply cable, lightning, etc;
- Internal systems such as the indoor floor and the entire structure.

To prevent damage from static electricity, you must pay attention to the following:

- Properly ground the equipment.
- Take dust prevention measures in the room.
- Maintain an appropriate humidity and temperature.
- Always wear an anti-static wrist strap when you touch any circuit board.
- Place the circuit board on an anti-static workbench or in an anti-static shielding bag.
- Try to hold a circuit board by its edges. Do not touch any components or the PCB.

2.2.4 Anti-Interference Requirements

The wireless controller is susceptible to external interference such as electromagnetic wave and current. Note that:

- Provide the power system with effective anti-interference measures.
- It is recommended that the wireless controller be installed far away from the grounding device.
- Keep the wireless controller away from high-power radio stations, radar stations, and high-frequency high-current devices.
- Use EMI shielding when necessary.

2.2.5 Installation Site Requirements

To install the wireless controller whether in the cabinet or on the workbench, pay attention to the following items:

- Ensure that enough space is reserved around the air inlet and exhaust vents for ventilation and heat dissipation. It is recommended that the wireless controller be installed in a standard 19-inch cabinet.
 Otherwise, use a clean platform as a workbench. It is recommended to equip the installation site with an air conditioner if it is hot.
- Ensure that the cabinet or the workbench is provided with proper ventilation and heat dissipation system.
- Ensure that the cabinet or the workbench is sound enough to bear the weight of the wireless controller and its accessories.

• Ensure that the cabinet or the workbench is properly grounded.


2.3 Installation Tools

Installation Tool	Cross screwdriver and anti-static wrist strap	
Cable	Power cord, configuration cable, Ethernet cable and grounding cable	
Device	Hub/switch, configuration terminal (such as PC with Hyperterm) and power socket	

3 Installing Wireless Controller

3.1 Installation Flowchart

Please follow the following procedure to install the wireless controller to ensure the smooth installation and avoid any damage to the device.



3.2 Mounting Wireless Controller

Now the wireless controller is ready for installation. Mount it to either of these two places.

- A cabinet
- A workbench

3.2.1 Mounting RG-WS6008 in Cabinet

RG-WS6008 is designed according to the specification of 19-inch standard cabinet. Use the supplied mounting accessory for installation.

3.2.2 Mounting RG-WS6008 on Workbench

In the absence of a 19-inch standard cabinet, install the wireless controller on a clean workbench. During the operation, pay attention to the following items:

- The workbench is firm and well-grounded.
- The supplied plastic cushion is stuck to the small hole at the bottom of the wireless controller and a 10 cm clearance is reserved for dissipation.
- No weight is placed on the top of the wireless controller.

3.3 Installing Power Cable

RG-WS6008 supports AC (100 VAC to 240 VAC; 50/60 Hz). Make sure that your power supply meets the requirement.



Note

See Chapter 1 for details about the power module.

RG-WS6008 uses three-wire power cable. It is recommended to use single-phase three-wire power socket or multi-functional microcomputer socket with neutral-point connector. The neutral-point needs to be grounded safely. Check whether the power supply in your building is grounded properly.


Follow the following steps to install the power cable:

- (1) Connect one end of the supplied power cable to the socket on the rear panel of the device and another to the AC power socket.
- (2) Check the power indicator on the front panel is on. If it is, it means that the power cable is correctly connected.

3.4 EMS & Secure Grounding

The ground required for EMC design includes shielding ground, filter ground, noise and interference suppression, and level reference. All the above constitute the comprehensive grounding requirements. The grounding resistance should be smaller than 1Ω . The RG-WS6008 wireless controller has a grounding pole on the rear panel, as shown in Figure 3-1.

Figure 3-1 RG-WS6008 Grounding



3.5 Connecting Console

RG-WS6008 supplies an EIA/TIA-232 configuration console for local configuration. If you configure RG-WS6008 through Web, skip this part.

Table 3-1 Console Attributes

Parameter	Description
Connector	RJ-45
Interface Standard	Asynchronous EIA/TIA-232
Baud Rate	57,600 bps, 115,200 bps, 9,600 bps (default)
	Command line interface
Supported Services	Connection to character terminals
	Providing terminal access service as an asynchronous interface

Connect one end of the supplied configuration cable to the console port of the wireless controller, and the other end to the DB-9 male serial adapter of the microcomputer.

3.6 Verification

When you have installed the wireless controller, before powering on it, pay attention to the following items:

- If the wireless controller is stalled in a cabinet, check the mounting brackets of the cabinet and wireless controller are firm. If the wireless controller is installed on the workbench, check there is enough room around the wireless controller for heat dissipation and the workbench is firm.
- Check the power supply meets the requirements.
- Check the grounding cable is correctly connected.

• Check the wireless controller is connected correctly to other devices such as the configuration terminal.



Caution

To shut down the device, turn off the power switch on the rear panel of the device. Do not directly disconnect the 220 V power supply, such as directly cutting off the power or unplugging the power cord. For details about the power switch, see Section 1.1 Product Appearance.

4 Configuration Guide

4.1 Setting up Configuration Environment

When you use the wireless controller for the very first time, you will need to configure it through a console port as follows:

- As shown in the following figure, connect the serial port of a character terminal or microcomputer to the console port through an RS232 cable.
- Set the communication parameters of the terminal. For a microcomputer, you will need to run a terminal emulation program like Windows operating system's Hyperterm. Take Hyperterm for example.
 - a Run Hyperterm and create a connection.
 - b Select the serial port to be connected with the console port of the wireless controller, as shown in figure 4-2.
 - c Set communication parameters as follows: baud rate to 9600, data bit to 8, stop bit to 1, parity to No, flow control to No, as shown in figure 4-3.
 - d Go to File->Property->Settings and set terminal emulation type to VT100.

Figure 4-1 Creating Connection



Figure 4-2 Selecting Serial Port to be Connected with Console Port.





Figure 4-3 Setting Communication Parameters for Serial Port.



After building the configuration environment, you may power on the wireless controller.

4.2 Powering on Wireless Controller

4.2.1 Verification Before Power-on

Before powering on the wireless controller, please check the following items:

- If the power cable and the grounding cable are connected correctly.
- If the power supply voltage meets the requirement.
- If the configuration cable is connected correctly, the microcomputer or terminal is turned on, and the setting
 is complete.

Note

Before powering on the wireless controller, check the position of the power switch so that you may cut power supply in time in case of accident.

4.2.2 Power-on

- Turn on the power supply.
- Turn the power switch of the wireless controller to the **on** position.

4.2.3 Verification After Power-on

After powering on the wireless controller, please check the following items:

If the ventilation system is functional.

When the wireless controller is powered on, you will hear the fan working. Put your hand near the air inlet and exhaust vents, you will feel the air flowing.

• If the indicators on the front panel of the wireless controller are in the proper state.

See LED Indicators in Chapter 1.

If the configuration terminal displays information as expected.

When the wireless controller is powered on, information on the software self-decompression will appear on the terminal display.

4.2.4 Startup Process

When the wireless controller is started for the first time, the following information appears:

```
0.000000] Linux version 2.6.32.13-Cavium-Octeon (ngcf@ngcf75) (gcc version 4.3.3
(Cavium Networks Version: 2 0 0 build 95) ) #1 SMP Thu May 8 04:34:42 CST 2014
    0.000000] CVMSEG size: 2 cache lines (256 bytes)
    0.000000] Cavium Inc. SDK-2.3
    0.000000] bootconsole [early0] enabled
    0.000000] CPU revision is: 000d910a (Cavium Octeon II)
    0.000000] Checking for the multiply/shift bug... no.
    0.000000] Checking for the daddiu bug... no.
    0.000000] Determined physical RAM map:
    0.000000] memory: 00000000003f000 @ 000000000dd1000 (usable after init)
    0.000000] memory: 000000000f000000 @ 000000000f00000 (usable)
    0.000000] memory: 00000000d0000000 @ 000000020000000 (usable)
    0.000000] memory: 000000000ffff000 @ 0000000f0001000 (usable)
    0.000000] memory: 000000030efff000 @ 000000100001000 (usable)
mount: Mounting /dev/sdal on /var/storage failed: No such device or address
Starting rg lowmem killer...
Starting snooping.elf...
                                                                [ OK ]
Starting postgresgl server...
/mnt/sata0/pgsql/bin/postgres not found...
                                                                   [ OK ]
Starting rg-mtdoops-cli...
                                                                [ OK ]
Starting sntp.elf...
                                                                [ OK ]
Press RETURN to get started
*May 15 11:08:01: %CAPWAP-4-NO IP ADDR: Please config the IP address for capwap.
```

Now the wireless controller is ready for configuration.

Note

- Such information may vary with hardware configuration or software version.
- When using the wireless controller for the first time, it is recommended to set basic parameters during configuration.

4.3 Configuring Wireless Controller

See RG-WLAN Series Access Controller RGOS Command Reference and RG-WLAN Series Access Controller RGOS Configuration Guide for configuration details.

5 Troubleshooting

5.1 Power Troubleshooting

You may use the power indicator on the front panel to decide if the power supply system is operating normally. For description of indicators, see Chapter 1. If a fault occurs, check the following items:

- If RG-WS6008 power switch is in the on position.
- If the power supply is turned on.
- If the power cord is connected correctly.
- If the power supply meets the requirements.

Caution

Never attempt hot swapping of the power cord. If the steps above did not solve your problem, contact your local distributor or technical support personnel.

5.2 System Troubleshooting

If the system is operational, relevant information is displayed on the terminal as described in chapter 4. Otherwise, nothing or gibberish is displayed. If nothing is displayed, please check the following items:

- Verify whether the system power supply is operational.
- Verify whether the cable is connected to the console port correctly.

If there is still nothing displayed, it may be due to improper cable connection or incorrect parameter settings. Please change the parameter settings.

If gibberish is displayed, it may be caused by incorrect parameter settings. Please check the following parameters:

Baud rate: 9600

Data bit: 8

Parity check: None

Stop bit: 1

Flow control: None

Terminal emulation: VT100

Note

If the console port parameters are changed, it may cause no display on the terminal.