



# DS-K3G200B(L)X Series Tripod Turnstile Video Guide

## Contents

Chapter 1 Open Upper Cover .....	1
Chapter 2 Remove Maintenance Door .....	2
Chapter 3 Movement Disc and Barrier Installation .....	3
Chapter 4 Main Switch Installation and Wiring .....	4
Chapter 5 Access Board Installation and Wiring .....	5
Chapter 6 Card Reader Installation and Wiring .....	6

## Chapter 1 Open Upper Cover

Refer to the open upper cover installation video for details:

Refer to the link to see the high-definition video: <https://enpinfodata.hikvision.com/analysisQR/showQR/fd4da5b7>

## Chapter 2 Remove Maintenance Door

Refer to the remove maintenance door installation video for details:

Refer to the link to see the high-definition video: <https://enpinfodata.hikvision.com/analysisQR/showQR/5355f6b3>

## Chapter 3 Movement Disc and Barrier Installation

Refer to the movement disc and barrier installation video for details:

Refer to the link to see the high-definition video: <https://enpinfodata.hikvision.com/analysisQR/showQR/113d65c1>

## Chapter 4 Main Switch Installation and Wiring

Refer to the main switch installation and wiring video for details:

Refer to the link to see the high-definition video: <https://enpinfodata.hikvision.com/analysisQR/showQR/84594f16>

## Chapter 5 Access Board Installation and Wiring


Refer to the access board installation and wiring video for details:

Refer to the link to see the high-definition video: <https://enpinfodata.hikvision.com/analysisQR/showQR/6a3b5994>

## Chapter 6 Card Reader Installation and Wiring

Refer to the card reader installation and wiring video for details:

Refer to the link to see the high-definition video: <https://enpinfodata.hikvision.com/analysisQR/showQR/7399a6c1>



See Far, Go Further