


MAXHUB Document Camera

Model: SC13B



Quick Start Guide

V1.1

MAXHUB

Table of Contents

I. Package Contents02

II. Product Introduction02

Safety Instructions

Before operating this product, read and follow the instructions carefully to avoid dangerous or illegal operations.

1. Operating Environment

- Do not use the device in damp or humid locations to avoid internal circuit damage.
- Avoid hot environments or areas with direct sunlight.
- Optimal temperature range for use: 0-40°C, humidity range: 10%-90% RH.

2. Child Safety

The device and its parts may include small components. Keep them out of reach of children to prevent accidents.

3. Battery

- Do not let children touch the battery.
- Avoid exposing the battery to fire to prevent fire hazards.
- Use the correct poles when connecting the battery to avoid short circuits.

4. Water Protection

This device is not waterproof. Keep the equipment dry.

5. Maintenance

- All maintenance should be carried out by qualified personnel. If the device malfunctions, do not disassemble it yourself.
- Avoid inserting objects into any of the ports to prevent damage.
- Do not drop or subject it to strong impacts or vibrations to avoid product damage.

Special Statements


- Intellectual Property Rights: The hardware design and software of this product are protected by copyright law. Unauthorized copying of the manual or any part of the product will subject violators to legal consequences.
- This manual is for reference only. The final actual functions are subject to the functions of the product ordered and received by the customer.
- The images are for reference only. Please refer to the actual product. Our company reserves the right to improve and change the product's appearance and design without prior notice.

I. Package Contents

1. Document camera × 1;
2. USB cable (A to B) × 1;
3. Wall-mount fixed bracket × 1;
4. Wall mount bracket × 1.

II. Product Introduction

Before using the device, please familiarize yourself with its buttons and ports.



No.	Item	Description
1	Light Adjustment Button	Tap to turn the fill light on/off, supports three-level adjustments.
2	Camera Button	Capture photos, captured photos are automatically saved and displayed on the display device.
3	AI Button	One-touch AI function activation.
4	Zoom Out	Zoom out the displayed content on the screen.
5	Zoom In	Zoom in the displayed content on the screen.
6	Pen Slot	Storage for the pen.
7	Camera	Captures and displays the content on the tray.
8	Fill Light	Provides adequate lighting for normal shooting in low-light conditions.
9	Microphone	Records audio.
10	Book Holder	Secures physical objects for display.
11	Tray	Placing objects for display.
12	USB Port	Used to connect to the display device.

Power On/Off Instructions:

- Power On: Opening the tray will automatically start the video software and enable the device to work.
- Power Off: Closing the tray will automatically shut down the software and turn off the device simultaneously.

